

Y-cable for control boxes

1 handset controlling 2 control boxes by using a Y-cable.

Please note that both control boxes needs to be re-programmed with special software for cascading. See customer site for re-programming of control box.



Connect
2 control boxes
NB: Must be the same model

Connect
1 handset

Reset

First time a desk is assembled and taken into use, the desk must be reset!

Step 1 - each desk:

Press both ▲ ▼ buttons at the same time for 3 seconds.

Continue pressing the buttons until both columns are in lowest position. Keep pressing the buttons, and control box will now make 1 beep. Now the buttons can be released.

Then unplug AC cable from the control box.

Step 2 – to activate 4 columns:

Connect y-cable to both control boxes and one handset. Then plug in both AC cables again and connect the power source.

Press both ▲ ▼ buttons until you hear **2 beeps** from 1 of the control boxes. Now buttons can be released, and you can run 4 columns.

Drawing

Standard dimension (mm)

